




Deskjet 1010 Series




CX015-90028


1



1




2




3


2




3




4




1




2




3



4



5




6




5



1



2



3

6



www.hp.com/support

Printed in [English]

Printed in [French]

Printed in [Korean]

Printed in [Spanish]

Printed in [Portuguese]

Printed in [Simplified Chinese]

© 2013 Hewlett-Packard Development Company, L.P.